

*EasyDECON® DF200**Instructions for Use*

EasyDECON DF200 Decontamination Solution is a blend that includes ordinary household substances such as those found in hair conditioner and laundry detergent. When used as directed, EasyDECON has been proven to neutralize a host of bacterial contaminants, mold spores and fungus including harmful mycotoxins.

**EASYDECON® PRECAUTIONARY STATEMENT**

EasyDECON is a skin and mucus membrane irritant and can cause irreversible eye damage. Do not get in eyes, on skin, or on clothing. We recommend the user wear protective eyewear (goggles, face shields or safety glasses), protective clothing and chemical resistant gloves. In the event of skin contact, wash the affected area with soap and water. For eye contact, flush with plenty of clean water for at least 15 minutes. If irritation persists, contact your physician. In the case of skin contact, immediately wash skin with soap and copious amounts of water while removing contaminated clothing and shoes. Wash contaminated clothing before reuse. If irritation develops get medical attention.

EasyDECON is harmful if swallowed or inhaled. The use of an air purifying respirator with organic vapor cartridge (APR) is recommended. Avoid breathing vapor or spray mist. If inhaled move to fresh air. If breathing becomes labored consider oxygen, get medical attention. The vapors may cause respiratory tract irritation. If ingested, contact a poison control center immediately.

EasyDECON is a powerful chemical. Care should be taken while using it. This product is designed to bacterial contaminants. Although it is environmentally friendly, all warnings and cautions must be followed.

EasyDECON will not damage or stain most fabrics and is safe to use on most surfaces.

**KIT COMPONENTS:**

The EasyDECON kit consists of:

- ✓ One Container of Part 1 (Surfactant)
- ✓ One Container of Part 2 (H<sub>2</sub>O<sub>2</sub>)
- ✓ One Container of Part 3 (Diacetin)
- ✓ One Stir Stick
- ✓ Material Safety Data Sheet



## MIXING INSTRUCTIONS:

The EasyDECON kit comes complete with everything necessary to mix and use.

### To prepare the solution:

- Select a well-ventilated area.
- Wear eye protection, protective clothing and chemical resistant gloves.
- Secure a **clean** mixing vessel to mix all of the components.
- Remove all of the contents from the kit.
  
- Select the Container, Part 1. Remove the cap and pour the entire contents into the mixing vessel.
- Select the Container, Part 2. Remove the cap and pour the entire contents into the mixing vessel.
- Select the container, Part 3. Remove the cap and pour the entire contents into the mixing vessel.
  
- Using the stir stick provided, gently stir the contents ensuring all three components are thoroughly blended.
  
- Mark the date and time of actual mixing on the outside of the mixing vessel.
- The solution will remain effective for **8 hours** after mixing all three components.
- Fill the tank reservoir of the application equipment to the desired fill mark.
  
- Apply the solution in accordance with standard operating procedures.

## CLEAN UP INSTRUCTIONS:

After the application process is complete, cleanup of any residual solution is accomplished using tap water and sponges or towels. Any surface coming into contact with EasyDECON will display a certain amount of residue.

The residue will feel dry yet tacky and can easily be wiped away using a damp sponge or towel. Rinse the sponge or towel often and change the rinse water frequently. After wiping away the residue simply dry the area with a lint-free cloth or towel.

## DISPOSAL INSTRUCTIONS:

Rinse the empty containers 3 times with fresh water and place the empty containers into a trash collection container. Upon completion, residual mixed solution must be properly disposed of. Always review the Material Safety Data Sheet (MSDS). Local, state and federal regulations must be adhered to when disposing any chemical into a sanitary sewer. Do not reuse or refill containers. To properly dispose of EasyDECON contact your local pesticide or Environmental Control Agency or take to a hazardous waste disposal site. Keep out of water supplies.